



Instructions - Sno-Cone Machine

WARNING: DO NOT USE AN EXTENSION CORD!

IMPORTANT NOTE: Machine must be properly grounded to prevent shock in case of electrical problems. The motor is 110 volt, single phase, 60 cycle, AC current.

CAUTION: Do not let any metal get down in the gooseneck, or you will ruin the blades. Never put your fingers or any object into the shaver body while the motor is running. Disregard for these instructions and careless handling will result in accidents and/or injury.

1. Start the motor and fill the gooseneck with ice cubes or block ice broken into 3" to 4" pieces in size. Fill to about an inch or so from the top, the larger the piece of ice the better the snow.
2. Push the pusher handle down to press the ice against the cutter head. A firm even pressure is all that is required, but sometimes you will find it better to relieve the pressure two or three times on the way down. This lets the ice rearrange itself and you get a better bite.
DO NOT FORCE THE HANDLE. The motor could be stalled.
3. When too much pressure is necessary, relieve the handle and then come down again. Too much pressure on the pusher handle will make the ice come out coarse; too little pressure makes the ice mushy.

IMPORTANT NOTE: In normal operations the motor gets warm. A surface temperature of 150 degrees is normal.

CLEANING

- Always unplug the machine before cleaning.
- Wipe all surfaces clean before returns to avoid additional cleaning charges.