



Instructions - Coffee Maker

Operating Instructions

1. Fill coffee pot with COLD water to desired amount. Water level marks are stamped into the side of the pot.
2. Wet the filter basket and add coffee grounds (see chart below). Make sure stem is set into the center well in the pot.
3. Put cover on and place pot on stable, level surface.
4. Plug coffee pot into standard 110 electrical outlet with NO EXTENSION CORDS or other heating/cooking devices.
5. After coffee has finished brewing (the “serve” light will turn on), carefully remove hot basket. The pot’s warmer will keep the coffee hot.

Brewing Time: Approximately 1 minute per cup of coffee. (Half hour for 30 cups, one hour for 60 cups, etc.)

Coffee Chart

# of Cups	Coffee Measure
30	2 cups
42	3 cups
60	3.5 cups
100	6 cups

*1 pound of coffee is equal to 4.75 cups of ground coffee (approx).

*NEVER IMMERSSE COFFEE POT IN WATER! Simply rinse out coffee pot and basket before returning.