



Instructions - Sterno Food Warmer / Hot Box

1. Begin by using four Sternos in the hot box.
The four will heat the box to approximately 160° F,
depending whether the box is used indoors or outdoors.
2. To increase the temperature, add more Sterno.

Cleaning

Throw away all debris and used Sterno.

Note:

To keep food from drying out, add a pan of water to the bottom of the unit.

Continually opening & closing the doors will cause temperature loss faster than the food warmer can recover.